


SA040 Work Light Mounting Instruction


Scope of delivery:

1 Lamp


2 Connecting line




A. Unscrew the nut and the gaskets




B. Attach lamp to a base. Add nut and washer and Spring washer to screw.



C. Loosen the fixing screws on both sides of the u-shaped bracket to adjust the angle of lamp, then fix it back



D. Connecting the lamp to battery.



Notes:

1 Remove the protective film from the lens after installation.

2 Please ensure there is no covering in front of the lighting direct.

3 If the additional cable set is needed, the min current should be $>5A$.

4 Waterproof sealing is a must for cable connect.

5 The lamp can be mounted in two ways: front mounted or back mounted

6 When the lamp is heated to 70° after electrification, the panel will stop heating, and when the temperature drops to 0° , the lamp will restart the heating function